



INSTRUCTIONS: POPCO1

Floor Coaster Display

Ceramic Coaster and Car Coasters & Hanging Signs


Includes:

- A. Spinner Base (1)
- B. Side Panel Connector (1)
- C. Reinforcement Panels (2)
- D. Side Panels (2)
- E. Pegboards (2)
- F. Topper (1)
- G. Hooks (56)
- H. Cross Dowel (4)
- I. Screw (4)

Notes:

- Two person assembly
- Optional tools: rubber mallet, Flat Head screwdriver


Provided: Allen wrench



Spinner Base




Side Panel Connector



Reinforcement Panels



Side Panels



Pegboards



Topper



Hooks



Cross Dowels



Screws

1. Place Spinner Base (A) on the floor with slots facing up.



2. Tap the Side Panel Connector (B) into place on the base using a rubber mallet or by using one of the Reinforcement Panels (C).




Note: Properly line up the piece before tapping it into place. The Reinforcement Panel (C) must be flat against the base while tapping the Side Connector Panel (B) into place.

3. Place one of the Side Panels (D) into slot on base, then repeat for the second Side Panel (D).



Note: May need to slightly angle Side Panel (D) before sliding into place.

4. Insert a Cross Dowel (H) into each circle opening in the Reinforcement Panels (C). Assure the slit in the Cross Dowel (H) is parallel using a Flat Head Screw Driver with the Reinforcement Panel openings (C).



5. Line up the Reinforcement Panels (C) with the slot on the inside of each Side Panel (D). Then, gently push the Screw (I) through the slot on the outside facing side panel (D) into the Reinforcement Panel (C). Use the Allen wrench to tighten. Repeat this for both Reinforcement Panels (C).



6. Slide Pegboards (E) into the slots on the Side Panels (D).

Note: The top of the Pegboards (E) have the holes closest to the edge. Display may need to be tilted for stores with lower ceilings to slide into place.



7. The Pegboards (E) should be level with the tops of the Side Panels (D). If they are not level, lightly tap or wiggle the bottoms of the Pegboards (E) until they slide into place.

Note: If boards are not fitting, try turning them around.



8. Place Topper (F) on top of the Side Panels (D).

Note: This should go on easily if lined up with Pegboards (E) properly.



9. Congratulations! Display is ready to load with product.



Filling in Product:

1. To use for Coaster 4-packs, place Hooks (G) on Pegboards (E) fitting one across. Repeat for Side Panels (D).



2. To use for Car Coaster 2-packs, place Hooks (G) on Pegboards (E) fitting two across. For Side Panels (D), one across.



3. To use for Hanging Signs, place Hooks (G) on Pegboards (E) fitting Hanging Signs one across. Repeat for Side Panels (D).

